

Room Temperature Sensor

Temperature sensor for rooms, Pt100 passive Sensor in hazardous locations zones 1, 2 and 22

Type TFR-2G3D ATEX compliant

APPLICATION

TFR-2G3D sensors for measuring room temperatures. In combination with Ex-i transducer Type EXL-IMU-1 with intrinsic safe circuit the sensor may be used in hazardous areas 1, 2 and 22. The passive potential free resistor output of Pt100 sensor is changed into an active signal of 0(2)... 10 V- and/or 0(4)... 20 mA. Applications area is non condense, aggressive air in living, work and office rooms as well as industriel areas...

TECHNICAL DATAS

 Type
 TFR-2G3D

 Supply
 by Ex-i transducer

 Sensor
 Pt100 DIN

 Accuracy
 Class B

 Sensor current
 < 2 mA</td>

 Ambient temperature
 -40...+60 °C

 Storage temperature
 -40...+70 °C

Connection screw clamps 0,14 - 1,5 mm²
Enclosure Plastic, IP65 acc. to EN 60529
Dimension and weight 64 x 72 x 35 mm, approx. 150 g

Protection class simple apparatus acc. to EN 60079-0 / EN 60079-11

CE 94/9/EC (ATEX)

Includes in price 1 room temperature sensor, Type TFR-2G3D Installation area Hazardous locations in zone 1, 2 and 22



Ex-i CIRCUITS - TABLE 1

Operation values maximum at terminal Simple apparatus suitable for Zone 1, 2 and 22 Only for connecting to intrinsically safe circuits with max values

 Voltage
 Uo
 7,5 VDC

 Current
 Io
 5 mA

 Power
 Po
 10 mW

 Capacity
 Ci
 0 μF

 Inductivity
 Li
 0 mH

MOUNTING AND INSTALLATION

Notes to mechanical installation. The installation must comply with relevant directives and standards Particularly with regard to:

- Comply with the EMC directive

Ex-i Module EXL-IMU-1

- Avoid parallel wiring of power cable this cause measurement errors.
- Recommendation: Use shielded cable. Connect shield at PLC or control room area, sensor side is open.

The maximum values must not be exceeded!

Please check your external capacities and inductivities in acc. to the length of the cable and the methode of installation.

RECOMMENDED TRANSDUCER

- Transducer Mfr. Schischek Type EXL-IMU-1.
- In combination with transducer EXL-IMU-1 is intrinsic safety proof for simple circuits given.
- Manufacturer declaration zone 1, 2 and 22.

ATTENTION!

- For installation, use and maintenance the official standards and rules must be applied.
- The energy of intrinsically safe circuits are below the level to start an explosion in case of a spark..
- Intrinsic safe circuits must be installed with light blue coloured and separate from non intrinsic safe circuits.
- The sensor is passiv and potential free for use in hazardous locations in zone 1, 2 and 22.
- Pay attention to the max values for wiring , listed in table 1.
- Avoid electrostatic discharge.
- · Only wet cleaning.
- After mounting the protection class IP65 acc. to EN 60529 must be fulfilled

